



**Product Information**


[Baja Web](#) > [Product Information](#) > [Parts Lists](#) > [MOTORCYCLE](#) > BV250 Tank 250cc Street Bike (VIN PREFIX)

BV250 Tank 250cc Street Bike (VIN PREFIX)**BV250 Tank 250cc Street Bike (VIN PREFIX)****Headlight [Image]****Headlight**

Item No	Part Number	Description	Baja Description	Qty
	BV250-628	HEADLIGHT HOLDER		1
001	BV250-100	HEADLIGHT ASSEMBLY		1
002	BV250-101	BULB	SMALLER OUTSIDE BULB	2
003	BV250-102	BULB, HEADLIGHT		2


Turn Signals [Image]**Turn Signals**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-103	FRONT LEFT FLASHER LIGHT ASSY		1
002	BV250-104	BULB(12V-10W)		1
005	BV250-105	SELF TAPPING SCREW, ST3.8*12		3
006	BV250-106	FRONT LIGHT FLASHER LIGHT ASSY		1
007	BV250-107	BULB(12V-10W)		1
010	BV250-105	SELF TAPPING SCREW, ST3.8*12		3


Speedometer [Image]**Speedometer**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-109	SPEEDOMETER ASSEMBLY		1
016	BV250-110	METER BRACKET WASHER		2
017	BV250-111	METER BUSHING		2
018	BV250-112	WASHER, PLATE		4
019	BV250-113	NUT		2
020	BV250-114	SPEEDOMETER CABLE		1

Handles [Image]


**Handles**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-115	HANDLEBAR (LEFT)		1
002	BV250-116	HANDLEBAR (RIGHT)		1
003	BV250-117	BOLT, FLANGE		2
004	BV250-118	BOOT		1
005	BV250-119	BOOT		1
006	BV250-120	CABLE, THROTTLE		1
007	BV250-121	CABLE, CLUTCH		1
008	BV250-122	BOOT, CABLE		1
009	BV250-123	CABLE, STARTER		1
010	BV250-124	LEFT REAR VIEW ASSY		1
011	BV250-125	RIGHT REAR VIEW ASSY		1
012	BV250-126	HANDLEBAR BALANCED PLUG		2
013	BV250-127	BOLT FOR BALANCED PLUG		2


Levers [Image]**Levers**

Item No	Part Number	Description	Baja Description	Qty
013	BV250-143	SWITCH, HANDLE RIGHT		1
014	BV250-144	SWITCH, HANDLE LEFT		1
018	BV250-145	FRONT STEP SWITCH LINK		1
019	BV250-146	CLAMP		2
020	BV250-131	CLUTCH LEVER ASSEMBLY		1
021	BV250-132	FRONT BRAKE LEVER ASSEMBLY WITH CALIPER		1

Front Brake [Image]


**Front Brake**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-229	DISC, BRAKE		2
002	BV250-230	BOLT		12
009	BV250-232	PADS, FRONT BRAKE		2


Steering Stem [Image]**Steering Stem**

Item No	Part Number	Description	Baja Description	Qty
007	BV250-153	UPPER STEERING STEM		1
008	BV250-154	BOLT, FLANGE M8*35		2
009	BV250-155	NUT, CROWN		1
010	BV250-156	LOCK COVER		1
011	BV250-157	ELECTRIC DOOR OPENER		1
012	BV250-158	BOLT, FLANGE M6*12		2
013	BV250-159	BOLT, FLANGE M6*16		2
014	BV250-128	BEARING ASSEMBLY, STEERING STEM		1

Front Shocks [Image]


**Front Shocks**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-160	FRONT LEFT SHOCK ABSORBER		1
016	BV250-161	FRONT RIGHT SHOCK ABSORBER		1
018	BV250-162	LOWER HANDLE CROWN WELDER		1
021	BV250-129	BOLT, ???		2


Rear Fender [Image]**Rear Fender**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-163	WASHER 6		4
002	BV250-164	BOLT M6*6		2
003	BV250-165	BOLT M6*45		2
004	BV250-166	RR.FENDER		1
005	BV250-167	RUBBER COMP RR.FENDER		4
006	BV250-168	CROSS BRIDGE SCREW		8
007	BV250-169	CLAMPING PIECE M6		8
008	BV250-170	FENDER COMP FRAME BODY		1

Front Wheel [Image]


**Front Wheel**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-171	FRONT WHEEL AXLE		1
002	BV250-172	GEAR BOX		1
003	BV250-173	OIL SEAL A		1
004	BV250-174	TRANSMISSION PIECE		1
005	BV250-175	BEARING 63027		2
006	BV250-176	FR.WHEEL, INNER TIRE		1
007	BV250-177	TIRE FRONT 100/90-16		1
008	BV250-178	FRONT WHEEL RIM		1
009	BV250-179	COLLAR, FR.WHEEL AXLE		1
010	BV250-180	OIL SEAL B		1
011	BV250-181	COLLAR		1
012	BV250-182	NUT M14*1.5		1
013	BV250-183	OPEN PIN 2*40		1

Rear Wheel [Image]**Rear Wheel**


Item No	Part Number	Description	Baja Description	Qty
001	BV250-184	RR. BRAKE SHOE		2
002	BV250-185	SPRING RR.BRAKE SHOE		2
003	BV250-186	CAM, RR.BRAKE		1
004	BV250-187	WASHER (F20*F13*2)		1
005	BV250-188	BOLT M6*35		1
006	BV250-189	RR.BRAKE SWING ARM		1
007	BV250-190	ADJUSTING NUT, RR.BRAKE SWING ARM		1
008	BV250-191	PIN COMP., RR.BRAKE CABLE		1
009	BV250-192	NUT M6		1

010	BV250-193	RR.WHEEL AXLE		1
011	BV250-194	R COLLAR, RR.WHEEL		1
012	BV250-195	RR.BRAKE PANEL		1
013	BV250-196	BOLT M8*25		1
014	BV250-197	BEARING		2
015	BV250-198	OIL SEAL		1
016	BV250-199	RR.WHEEL RIM		1
017	BV250-200	INNER TIRE, RR.WHEEL		1
018	BV250-201	OUTER TIRE, RR.WHEEL		1
019	BV250-202	RUBBER		4
020	BV250-203	COLLAR		4
021	BV250-204	RUBBER COLLAR, OUTER		1
022	BV250-205	COLLAR A		1
023	BV250-206	COLLAR B		1
024	BV250-207	WASHER (F65*F58*2)		1
025	BV250-208	LOCKED BOLT, SPROCKET		4
026	BV250-209	CHAIN, 520 / 53 LINKS	CHAIN, 520 / 53 LINKS	1
027	BV250-210	SPROCKET CAM		1
028	BV250-211	FLANGE NUT M10		4
029	BV250-212	CHAIN SPROCKET RING		1
030	BV250-213	SCREW		4
031	BV250-214	WASHER (F70*F54*1)		1
032	BV250-215	WASHER (F27*F15*2)		1
033	BV250-216	CLIP SPRING		1
034	BV250-217	WASHER (F27*F15*2)		1
035	BV250-218	NUT M14		1
036	BV250-219	RR.BRAKE CABLE		1
037	BV250-220	SPRING COMP.,RR.BRAKE CABLE		1


Front Brake Master Cylinder [Image]**Front Brake Master Cylinder**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-221	MASTER CYLINDER ASSY		1
005	BV250-222	SCREW, FLAT HEAD		1
006	BV250-223	BRACKET, MASTER CYLINDER		1
007	BV250-224	BOLT, FLANGE		1
008	BV250-225	FRONT BRAKE HOSE ASSY		2
009	BV250-226	BOLT, UNION		2
010	BV250-227	WASHER, PLATE		4
011	BV250-228	LOWER HOSE BRACKET		2

Fuel Tank [Image]


**Fuel Tank**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-233	FUEL TANK COMP		1
002	BV250-234	DAMPER, LOCATING		2
003	BV250-235	DAMPER, LOCATING		1
004	BV250-236	BUSHING		1
005	BV250-237	BOLT, FLANGE		1
006	BV250-238	FUEL COCK ASSY		1
009	BV250-240	BOLT, HEXAGON SOCK		3
010	BV250-241	BOLT		1
011	BV250-242	PIPE, FUEL		1
013	BV250-243	BOLT, HEXAGON SOCK		3
016	BV250-245	CARBON POT COMP		1


Seat [Image]**Seat**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-246	DOUBLE SEAT ASSY		1
003	BV250-247	BRACKET, SEAT		1
004	BV250-248	NUT, FLANGE M6		1
005	BV250-249	PAD, SEAT		8
006	BV250-250	CLIP		1
007	BV250-251	PLATE		1
008	BV250-252	NUT, FLANGE M6		2
009	BV250-253	CABLE, SEAT LOCK		1
011	BV250-255	BOLT		2
012	BV250-256	CLAMP		1
013	BV250-257	REAR HANDLE GRIP		1

014	BV250-258	BOLT, FLANGE M8*40	2
015	BV250-259	BOLT, FLANGE M8*20	2
016	BV250-260	COLLAR	2
017	BV250-261	WASHER, PLATE	4
018	BV250-262	WASHER, PLATE	2


Tank Covers [Image]**Tank Covers**

Item No	Part Number	Description	Baja Description	Qty
	BV250-627	FRONT FENDER		1
001	BV250-263	METER BRACKET		1
002	BV250-264	BOLT, FLANGE		1
003	BV250-265	WING SHIELD		1
004	BV250-266	BOLT M6*16		6
005	BV250-267	NUT, FLANGE		6
006	BV250-268	WASHER		6
007	BV250-269	FIRING UPPER BOD		1
008	BV250-270	SCREW, TAPPING		10
009	BV250-271	LEFT FIRING		1
010	BV250-272	SCREW, M5*12		1
011	BV250-273	WASHER, PLATE		2
012	BV250-274	RIGHT FIRING		1
013	BV250-275	SCREW		2
014	BV250-276	WASHER, PLATE		2
015	BV250-277	COVER		1


Ferrings [Image]**Ferrings**

Item No	Part Number	Description	Baja Description	Qty
---------	-------------	-------------	------------------	-----

001	BV250-278	LEFT SIDE COVER	1
002	BV250-279	RIGHT SIDE COVER	1
003	BV250-280	GROMMET	2
004	BV250-281	SCREW, WITH WASHER M6*16	2
005	BV250-282	SCREW, WITH WASHER M6*12	2
006	BV250-283	BOX, BATTERY	1


Mainstand [Image]**Mainstand**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-284	STAND, SIDE		1
002	BV250-285	SIDE STAND TENSION SPRING		1
003	BV250-286	SIDE STAND BOLT		1
004	BV250-287	BOLT, STUD		1
005	BV250-288	MAIN STAND		1
006	BV250-289	SHAFT, MAIN STAND		1
007	BV250-290	PIN		1
008	BV250-291	MAIN STAND TENSION SPRING		1

Footrests [Image]**Footrests**


Item No	Part Number	Description	Baja Description	Qty
	BV250-625	PEDAL ASSEMBLY, GEARSHIFT		1
001	BV250-292	L BRACKET, FOOTREST		1
002	BV250-293	L FRONT FOOTREST ASSY		1
005	BV250-294	BOLT		1
006	BV250-295	BOLT		2
007	BV250-296	R BRACKET, FOOTREST		1
008	BV250-297	R FRONT FOOTREST ASSY		1

011	BV250-298	COLLAR	1
012	BV250-299	WASHER	1
013	BV250-300	NUT	1
014	BV250-301	SPRING, RETURN	1
015	BV250-302	PIN, COTTER	1
016	BV250-303	BOLT, FLANGE	1
017	BV250-304	NUT	1
018	BV250-305	BOLT	2
019	BV250-306	BOLT	4
020	BV250-307	L BRACKET	1
021	BV250-308	R BRACKET	1
022	BV250-309	R DAMPER, FOOTREST	1
023	BV250-310	BOLT	4
024	BV250-311	R REAR FOOTREST ASSY	1
027	BV250-312	L REAR FOOTREST ASSY	1
030	BV250-313	PIN COTTER	2
031	BV250-314	PEDAL, BRAKE	1
032	BV250-315	ROD, BRAKE	1
033	BV250-316	WASHER	1
034	BV250-317	PIN, CLEVIS	1
035	BV250-318	SPRING, COMPRESSION	1
036	BV250-319	PIN	1
037	BV250-320	NUT, WING	1

Frame [Image]**Frame**


Item No	Part Number	Description	Baja Description	Qty
001	BV250-321	FRAME COMP		1
002	BV250-322	BOLT M8*70		3
003	BV250-323	ENGINE FITTING PLATE, RIGHT		1
004	BV250-324	ENGINE FITTING PLATE, LEFT		1
005	BV250-325	NUT M8		3
006	BV250-326	NUT M8		4
007	BV250-327	BOLT M8*65		2
008	BV250-328	BOLT M8*90		2
009	BV250-329	BOLT M8*30		2

Rear Suspension [Image]


**Rear Suspension**

Item No	Part Number	Description	Baja Description	Qty
	BV250-631	CHAIN ADJUSTER ASSEMBLY		2
001	BV250-330	SWING ARM COMP		1
002	BV250-331	BOLT		1
003	BV250-332	SPACER		2
004	BV250-333	SHAFT RR.SWING ARM		1
005	BV250-334	NUT M12*1.25		1
006	BV250-335	WASHER 12		1
007	BV250-336	BUFFER CHAIN		1
008	BV250-337	BOLT M6*16		1
009	BV250-338	CHAIN CASE		1
010	BV250-339	BOLT M6*12		2
011	BV250-340	SHOCK ABSORBER BRACKET		1
012	BV250-341	WASHER		2
013	BV250-342	BOLT M12*1.25*75		1
014	BV250-343	WASHER		1
015	BV250-344	NUT M12*1.25		1
016	BV250-345	BRACKET		1
017	BV250-346	OIL SEAL		4
018	BV250-347	COLLAR 18*47		2
019	BV250-348	BOLT M12*1.25*75		2
020	BV250-349	WASHER		2
021	BV250-350	NUT, SELF-LOCKING		2
022	BV250-351	CENTER SHOCK ABSORBER		1
023	BV250-352	BOLT M12*1.25*60		1
024	BV250-353	BOLT M12*1.25*75		1
025	BV250-354	COLLAR		1
026	BV250-355	WASHER		1
027	BV250-356	NUT, SELF-LOCKING		1

Taillight [Image]


**Taillight**

Item No	Part Number	Description	Baja Description	Qty
002	BV250-357	L REAR TURNING LIGHT		1
003	BV250-358	TAILLIGHT BULB		1
007	BV250-359	TAILLIGHT ASSEMBLY		1
008	BV250-360	R REAR TURNING LIGHT		1


Electrical 1 [Image]**Electrical 1**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-361	C.D.I UNIT ASSY		1
003	BV250-362	HORN		2
004	BV250-363	BOLT, FLANGE		2
005	BV250-364	REAR REFLECTOR ASSY		1
006	BV250-365	NUT, FLANGE		1
007	BV250-366	STOP SWITCH ASSY		1
008	BV250-367	MAIN WIRE HARNESS ASSY		1
009	BV250-368	STARTER RELAY ASSY		1
010	BV250-369	NUT, FLANGE		2

Electrical 2 [Image]

**Electrical 2**

Item No	Part Number	Description	Baja Description	Qty
	BV250-626	REMOTE START		1
001	BV250-370	IGNITION SWITCH WITH KEYS, FUEL CAP, SEA		1
003	BV250-372	BOLT, FLANGE		2
004	BV250-373	RECTIFIER REGULAR		1
005	BV250-374	BOLT		2
006	30-01-9001	BATTERY (12N9-4B-1-FP)		1
007	BV250-376	HOSE (L350)		1
008	BV250-377	BAND, BATTERY		1
009	BV250-378	WIRE, PLUS LEAD		1
010	BV250-379	WIRE, MINUS LEAD		1
011	BV250-380	RELAY ASSY		1
012	BV250-381	IGNITION COIL ASSY		1
013	BV250-382	SCREW, PAN HEAD		2
015	BV250-384	FLASHER RELAY ASSY		1
016	BV250-385	FUEL LEVEL SENSOR		1
017	BV250-386	GASKET, SENSOR UNIT		1
018	BV250-387	BOLT, WASHER BASED		4


Exhaust [Image]**Exhaust**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-388	MUFFLER, RIGHT		1
001-1	BV250-231	MUFFLER, LEFT		1
002	BV250-389	FLANGE BOLT M8*45		2
003	BV250-390	NUT WITH CAP M8		2
004	BV250-391	MUFFLER AIRPROOF WASHER		2

005	BV250-392	HEXANGULAR LOCKNUT M8	4
006	BV250-393	MUFFLER LIE-IN SNAP RING	4
007	BV250-394	MUFFLER CLIP	2

Cylinder Head [Image]


w

**Cylinder Head**


w

Item No	Part Number	Description	Baja Description	Qty
001	BV250-395	HEAD COMP CYLINDER		1
002	BV250-396	HOSE CONNECTOR		1
003	BV250-397	HOSE CONNECTOR SETTING PLATE		1
004	BV250-398	O-RING F17*1.8		1
005	BV250-399	LEFT MANIFOLD,INTAKE		1
006	BV250-400	WASHER		2
007	BV250-401	SCREW		2
008	BV250-402	O-RING		2
009	BV250-403	RIGHT MANIFOLD,INTAKE		1
010	BV250-404	RUBBER,MOUNTING		2
011	BV250-405	PLUG,SPARK A6RTC		2
012	BV250-406	COVER,CYLINDER HEAD		1
013	BV250-407	BOLT SPECIAL		2
014	BV250-408	PACKING,HEAD COVER		1
015	BV250-409	CONNECT SCREW OF COVER		4
016	BV250-410	NUT,HEX M8		8
017	BV250-411	WASHER		8
018	BV250-412	VALVE,IN		2
019	BV250-413	VALVE,CX		2
020	BV250-414	RETAINER,VALVE SPRING		4
021	BV250-415	SEAT,VALVE SPRING OUTER		4
022	BV250-416	SPRING,VALVE INNER		4
023	BV250-417	SPRING,VALVE OUTER		4
024	BV250-418	COTTER,VALVE		8
025	BV250-419	SEAL,VALVE STEM		4
026	BV250-420	BOLT STUD OF ESCAPE PIPE		4
027	BV250-421	PIN,DOWEL 10*16		4
028	BV250-422	BOLT M6*145		2
029	BV250-423	BOLT M6*65		1
030	BV250-424	NUT M6-ZnD		1
031	BV250-425	PIN,DOWEL(10*28)		2
032	BV250-426	NUT M6-ZnD		4
033	BV250-427	BOLT STUD M6*29		4
034	BV250-428	SIDE COVER,CYLINDER HEAD		2
035	BV250-429	BAND INSULATOR(21?44)		2
036	BV250-430	CAP NUT		4
037	BV250-431	SEALING BOLT		2

038	BV250-432	BOLT M6*83	1
039	BV250-433	BOLT M6*12	1


Cylinder [Image]**Cylinder**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-434	CYLINDER COMP		1
002	BV250-435	PIN,DOWEL (8*14)		2
003	BV250-436	GASKET,CYLINDER		1
004	BV250-437	GASKET,CYLINDER		1

Crankcase [Image]**Crankcase**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-438	LEFT CRANKCASE		1
002	BV250-439	CONTACT NEUTRAL SWITCH		1
003	BV250-440	PROTECTING JACKET NEUTRAL SWITCH		1
004	BV250-441	PLATE,NEUTRAL SWITCH SETTING		1
005	BV250-442	SUB CORD NEUTRAL SWITCH		1
006	BV250-443	PROTECTING JACKET,ALTEMATOR OUTLINE		1
007	BV250-444	RUBBER PIPE COVER		1
008	BV250-445	O-RING(6*3)		2
009	BV250-446	SCREW M6*16		3
010	BV250-447	PLATE,OIL THROUGH		1
011	BV250-448	BEARING 6305/P6		2
012	BV250-449	OIL SEAL (35*52*7)		1
013	BV250-450	BEARING 6202-Z/P6		1
014	BV250-451	BEARING 22*7*14-RS/P6		1
015	BV250-452	OIL SEAL(22*34*7)		1

016	BV250-453	OIL SEAL(11.6*24*10)	1
017	BV250-454	RIGHT CRANKCASE	1
018	BV250-455	ROLLER BEARING 6304/P6	1
019	BV250-456	NEEDLE-BEARING HK152312	1
020	BV250-457	GASKER,RIGHT CRANKCASE COVER	1
021	BV250-458	BOLT M6*40	8
022	BV250-459	BOLT M6*12	1
023	BV250-460	PIN,DOWEL 12*20	2
024	BV250-461	GASKET,SIDE SPACER	1
025	BV250-462	GASKET,CRANKCASE	1
026	BV250-463	BOLT M6*65	2
027	BV250-464	SCREW M12*1.5	1
028	BV250-465	WASHER 12	1
029	BV250-466	BOLT,CYLINDER HEAD STUD	8
030	BV250-467	BOLT M8*1*35	4
031	BV250-468	BOLT M7*26	1
032	BV250-469	SCREW M6*32*ZnD	3
033	BV250-470	BOLT M8*1*30	1
034	BV250-471	PIN,SHIFT	1
035	BV250-472	PIN,DOWEL(8*14)	4

Crankshaft [Image]**Crankshaft**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-473	CRANK SHAFT COMP		1
002	BV250-474	PISTON		2
003	BV250-475	PIN,PISTON		2
004	BV250-476	1ST PISTON RING		2
007	BV250-479	CLIP ,PISTON PIN		4
008	BV250-480	CHAIN STRETCHING COMP		1
009	BV250-481	GUIDE,CAM CHAIN		1
010	BV250-482	GEAR,PRIMARY DRIVE		1
011	BV250-483	GEAR,OIL PUMP DRIVE		1
012	BV250-484	WASHER,LOCK		1
013	BV250-485	NUT,KEX M16*1		1
014	BV250-486	BOLT,ROTOR SETTING		1
015	BV250-487	SPROCKET COMP,STARTING		1
016	BV250-488	WASHER 12		1
017	BV250-489	STUD 2*14		1
018	BV250-490	SPRING,OIL THROUGH		1
019	BV250-491	THROUGH OIL		1
020	BV250-492	BOLT M6*26		2
021	BV250-493	WASHER 6		2
022	BV250-494	OIL SEAL 22*31*5		1

Camshaft [Image]




Item No	Part Number	Description	Baja Description	Qty
001	BV250-497	CAMSHAFT		1
002	BV250-498	BUSH,CAMSHAFT		2
003	BV250-499	PIN,DOWEL BUSH CAMSHAFT		2
004	BV250-500	WASHER,THRUST		1
005	BV250-501	CIRCLIP,EXTERNAL		1
006	BV250-502	HOLDER COMP,CAMSHAFT		2
007	BV250-503	HOLDR,CAMSHAFT	AVAILABLE WITH BV250-502	2
008	BV250-504	SHAFT,VALVE ROCKER ARM	AVAILABLE WITH BV250-502	4
009	BV250-505	SPRING,ROCKER ARM SIDE	AVAILABLE WITH BV250-502	4
010	BV250-506	ARM,VLAVE ROCKER	AVAILABLE WITH BV250-502	4
013	BV250-509	SPROCKET,CAM		1
014	BV250-510	BOLT M7*13		2
015	BV250-511	CHAIN,CAM		1

Oil Pump [Image]




Item No	Part Number	Description	Baja Description	Qty
001	BV250-512	PUMP ASSY,OIL		1


Clutch [Image]

**Clutch**


Item No	Part Number	Description	Baja Description	Qty
001	BV250-527	OUTER COMP,CLUTCH		1
002	BV250-528	CENTRE FRAME COMP		1
014	BV250-540	WASHER		1
015	BV250-541	CIRCULAR NUT		1
016	BV250-542	WASHER,THRUST		1
017	BV250-543	PUSHING BEARING		1

Left Crankcase Cover [Image]**Left Crankcase Cover**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-544	COVER,LEFT CRANKCASE		1
002	BV250-545	CLAMPER,CORD		1
003	BV250-546	SCREW,SOCKET M5*30-ZnD		1
004	BV250-547	SCREW M14*1.5		1
005	BV250-548	SCREW M30*1.5		1
006	BV250-549	O-RING 13.8*25		1
007	BV250-550	O-RING 27.4*2.4		1
008	BV250-551	SCREW,SOCKET M6*20-ZnD		2
009	BV250-552	SCREW,SOCKET M5*30-ZnD		3
010	BV250-553	GASKET,LEFT CRANKCASE COVER		1
011	BV250-554	SPACER COMP,LEFT SIDE		1
012	BV250-555	PLATE,STARTING SPROCKET SETTING		1
013	BV250-556	BOLT M6*10-ZnD		1
014	BV250-557	BOLT M6*20		1
015	BV250-558	BOLT M6*50		1
016	BV250-559	BOLT M6*65		5


Right Crankcase Cover [Image]**Right Crankcase Cover**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-560	COVER COMP,RIGHT CRANKCASE		1
002	BV250-561	LEVEL COMP,CLUTCH		1
003	BV250-562	BEARING HK1210		2
004	BV250-563	OIL SEAL 12*18*5		1
005	BV250-564	PIN,CLUTCH FILTER		1
006	BV250-565	RECEIVER,CLUTCH CABLE		1
007	BV250-566	GAUGE,OIL LEVEL		1
008	BV250-567	O-RING,F18*3		1
009	BV250-568	SPRING,CLUTCH LEVER		1
010	BV250-569	BOLT M6*40		7
011	BV250-570	BOLT M6*50		3


Left Rear Crankcase Cover [Image]**Left Rear Crankcase Cover**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-571	LEFT REAR CRANKCASE COVER		1
002	BV250-572	BOLT M6*46		1
003	BV250-573	BOLT M6*46		1

Carburetor [Image]


**Carburetor**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-574	CARBURETOR ASSY		1


Starter Motor [Image]**Starter Motor**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-575	BOLT M6*22		2
002	BV250-576	STARTING MOTOR		1
003	BV250-577	BOLT M6*65		2
004	BV250-578	SPROCKET ,STARTING MOTOR		1
005	BV250-579	CHAIN ,STARTING		1
006	BV250-580	CABLE,STARTING MOTOR		1
007	BV250-581	SWITCH ASSY,STARTING MAGNETIC		1
008	BV250-582	O-RING 33.5*1.8		1

Magneto [Image]


**Magneto**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-583	FLYWHEEL COMP		1
002	BV250-584	STARTER COMP		1
003	BV250-585	STARTING CLUTCH		1
004	BV250-586	SCREW M6*14-ZnD		3
006	BV250-588	COIL COMP		2
007	BV250-589	RECTIFIER ASY,REGULATE		1
008	BV250-590	IGNITER		1

Transmission [Image]**Transmission**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-591	MAINSHAFT COMP		1
009	BV250-599	COUNTERSHAFT COMP		1
018	BV250-608	SPROCKET,COUNTER SHAFT		1
019	BV250-609	PLATE, FIXING		1
020	BV250-610	BOLT M6*10-ZnD		2

Gearshift Drum [Image]

**Gearshift Drum**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-611	SPINDLE COMP,GEARSHIFT		1
002	BV250-612	STOPPER COMP,GEARSHIFT DRUM		1
003	BV250-613	SPRING,SHIFT DRUM STOPPER		1
004	BV250-614	WASHER 6		1
005	BV250-615	SCREW M6*12		1
006	BV250-616	FORK,LEFT GEARSHIFT		1
007	BV250-617	FORK,CENTER GEARSHIFT		1
008	BV250-618	FORK,GEARSHIFT		1
009	BV250-619	SHAFT,GEARSHIFT FORK GUIDE		1
010	BV250-620	PLATE,DRUM STOPPER		1
011	BV250-621	PIN,GEARSHIFT DRUM		4
012	BV250-622	SCREW M6*20		1
013	BV250-623	DRUM,GEARSHIFT		1
014	BV250-624	ROTOR,NEUTRAL SWITCH		1

Engine [Image]**Engine**

Item No	Part Number	Description	Baja Description	Qty
001	BV250-630	ENGINE (250CC MOTORCYCLE)		1